



## INDEX

- A
- ACCESSORIES . . . . . 9-1
- AIR CLEANER . . . . . 0B-4, 0B-5, 0B-6
- AIR CONDITIONING . . . . . 1B1-1
- Compressor . . . . . 1D-1
- Diagnosis . . . . . 1B1-8
- Diagnostic Connector . . . . . 1B1-14
- General A/C Information . . . . . 1B1-1
- Performance Chart
- Starfire, Omega, Cutlass, 88 & 98 . . . . . 1B1-9
- Toronado . . . . . 1B1-13
- Pressure Switch . . . . . 1B1-2
- Tempmatic . . . . . 1C-1
- AIR INJECTOR REACTOR PUMP . . . . . 6-18, 6E-3
- AIR SHOCK . . . . . 3D-14
- ALIGNMENT
- Axle Housing
- Except Toronado . . . . . 3D-8
- Drive Line
- Except Toronado . . . . . 4A-7
- Frame . . . . . 2A-1
- Front Wheel
- Except Toronado . . . . . 3A-2
- Toronado . . . . . 3A-3
- ANTENNA - RADIO . . . . . 9-37, 9-38, 9-39
- AXLE - DRIVE
- Toronado . . . . . 4C-18
- AXLE - HOUSING
- Except Toronado . . . . . 4B-10
- AXLE RATIOS AND IDENTIFICATION . . . . . 4B-33
- AXLE
- Shaft
- Type B . . . . . 4B-11
- Type All Except B . . . . . 4B-10
- Bearing and Seal
- Type B . . . . . 4B-12
- Type All Except B . . . . . 4B-11
- Toronado . . . . . 3D-9
- Spindle - Rear
- Toronado . . . . . 3D-10
- B
- BACK PRESSURE EXHAUST GAS  
RECIRCULATION VALVE . . . . . 6E-17
- BACK-UP LAMPS AND SWITCH . . . . . 8A1-44
- BALANCE - WHEEL AND TIRE . . . . . 3E-4
- BALL JOINT
- All Series . . . . . 3C-1
- BAR - TORSION . . . . . 3C-27
- BATTERY
- Boosting - Jump Starting . . . . . 6D-18
- Usage Chart . . . . . 6D-46
- Maintenance . . . . . 0B-1, 6D-18
- BODY MOUNTS . . . . . 2A-5
- BRAKES . . . . . 5-1
- Disc . . . . . 5-24
- Hydro-Boost . . . . . 5-46
- Line Repair . . . . . 5-10
- Fluid Recommendations . . . . . 0B-3, 5-9
- Master Cylinder . . . . . 5-22
- Parking Brake . . . . . 5-18
- Parking Brake Warning Lamp Switch . . . . . 5-19
- Power Cylinder - Moraine . . . . . 5-36
- Stop Lamp Switch . . . . . 5-8
- Warning Light . . . . . 5-19
- Wheel Cylinder . . . . . 5-34
- BULBS
- Specifications . . . . . 8A1-49
- Removal . . . . . 8A1-45
- BUMPERS . . . . . 2B-1
- BUTTON
- Horn . . . . . 3B4-5
- BUSHING - SERVICE
- Turbo Hydra-Matic 200 & 350 . . . . . 7A1-65, 7A3-52
- Turbo Hydra-Matic 400 & 425 . . . . . 7A4-131
- BUZZER, KEY-WARNING . . . . . 3-7
- C
- CAMSHAFT IDENTIFICATION . . . . . 6A3-30, 6A5-46
- CAMSHAFT & BEARINGS . . . . . 6A1-1, 6A2-18, 6A3-30, 6A4-15, 6A5-46
- CANISTER PURGE - TVS . . . . . 6E-19
- CAPACITIES . . . . . 0B-16, 0B-17
- CARBURETOR
- Model - 5210-C . . . . . 6C1-1
- Model - 6510-C . . . . . 6C1-15
- Model - 2GE-2GC . . . . . 6C1-27
- Model - M2MC . . . . . 6C1-49
- Model - M4MC . . . . . 6C1-71
- Adjustment Chart
- Model - 5210-C . . . . . 6C1-4
- Model - 6510-C . . . . . 6C1-18
- Model - 2GE-2GC . . . . . 6C1-42
- Model - M2MC . . . . . 6C1-62
- Model - M4MC . . . . . 6C1-87
- Diagnosis Chart . . . . . 6-5
- CAR MODEL IDENTIFICATION . . . . . 0A-1
- CARRYING HEIGHTS
- Except Toronado . . . . . 3A-4
- Toronado . . . . . 3A-4
- CATALYTIC CONVERTER . . . . . 6F-1
- CHARGING CIRCUIT OPERATION . . . . . 6D-18
- CHASSIS LUBRICATION . . . . . 0B-4, 0B-5, 0B-6, 0B-10
- CHASSIS SHEET METAL . . . . . 2C-1
- CHASSIS SPRINGS
- Front
- All Series . . . . . 3C-9
- Rear
- Except Toronado . . . . . 3D-6
- Toronado . . . . . 3D-11
- CHOKE RELAY CIRCUIT V-6 . . . . . 6D-37
- CHOKE THERMAL VACUUM SWITCH . . . . . 6E-20
- CIRCUIT DIAGRAMS - WIRING All Series . . . . . Section 8A1
- CITIZENS BAND RADIO . . . . . 9-34
- CLOCK
- Starfire . . . . . 8A2-4
- Omega . . . . . 8A3-3
- Cutlass . . . . . 8A4-3
- 88 and 98 . . . . . 8A5-3
- Toronado . . . . . 8A6-4
- CLUSTER - SPEEDOMETER
- Starfire . . . . . 8A2-2
- Omega . . . . . 8A3-2
- Cutlass . . . . . 8A4-5
- 88 and 98 . . . . . 8A5-3
- Toronado . . . . . 8A6-8
- CLUTCH
- Starfire . . . . . 7C-3
- Omega & Cutlass . . . . . 7C-7
- CLUTCH START SWITCH . . . . . 8A1-44
- COIL - IGNITION . . . . . 6D-34
- COLD ENGINE AIR BLEED - TVS . . . . . 6E-19
- COMPRESSION TEST . . . . . 6A5-18, 6E-2











